

# Tips and helpful resources for Moldflow



# Agenda

- 01 Personal introduction
- 02 Keep updated, get support
- 03 Moldflow Synergy tips
- 04 Valuable resources



# Introduction



 AUTODESK

# Who's presenting today?

## We all have a story

- Industry background:
  - 20 years career on automotive industry tier 1 companies.
  - 10 of them as a Moldflow analyst, 150-200 projects per year (executed and supervised combined).
- Tenure at Autodesk:
  - Joined 7 years ago.
  - Based in the Barcelona (Spain) office.
  - Jack of all trades and master of some. Special skills:
    - Anyone running Moldflow on Linux or HPC?
    - Synergy API scripting.

# Autodesk Support

Your trusted partner



 **AUTODESK**

# Support by Autodesk

## How and where

- How familiar are you with Autodesk Customer Support?
- Give the in Moldflow Autodesk Assistant a try! Answers based on the Moldflow help and Autodesk Knowledge articles.
- Autodesk Assistant on the Autodesk site, the door to Autodesk support team:
  - Article suggestion based on the prompt.
  - Forwarded to support team when needed.
- Main options, depending on contract: Web support, or Schedule a Call (have a specialist call you)
- Knowledge Articles are findable through regular web search.
- We like hearing from you, provide feedback on case closure:
  - Autodesk Support in general, and the individual specialist.

# Keep Moldflow updated

## Apply updates, try latest release

- Moldflow 2027 is live! [Announcement in the Moldflow forum](#).
- Moldflow software is updated by:
  - Complete side-by-side updates, which can coexist (2021.1, 2021.2).
  - On-top updates, which modify the existing installation (2026 becomes 2026.0.1).
- Some components have now individual update schedules:
  - From Moldflow team: Moldflow Material database, Moldflow Python API.
  - General components: Autodesk Licensing Service, Autodesk Shared Components.
- Where to get them:
  - Product updates section in Autodesk Account (<https://manage.autodesk.com/products/updates>)
  - Autodesk Access app.



# Synergy tips

Options, meshing, and automation



 AUTODESK



# Options

## Mesh using Synergy


- Mesh with Insight consumes a slot from the defined job limit.
- Mesh with Synergy to use specific queue and job limit:
  1. Click Options.
  2. Navigate to Compute Manager Tab.
  3. Enable “Mesh using Synergy”.



# Options

## Customize mouse button


- On large monitors apply button is far away from last click location.
- Save time and movements by configuring center mouse button:
  1. Navigate to Mouse tab.
  2. Set “Middle” to “Mouse Apply”.



# Options

## Customize duplicate behavior

- Default behavior:
  - “include results linked from the original study”.
  - Intends saving disk space.
  - Same result file is shared by multiple studies, risk of losing results.
- My recommendation:
  - Use “Do not include any results”, to not have results linked.
  - When intended, set “Include all results files”. Use cases:
    - Cool+Fill+Pack, reuse Cool but run Fill and Pack again.
    - Fill+Pack+Warp, reuse Fill and Pack and rerun Warp.




# Options

## Predictable import folder

- Default behavior: Import from last used folder.
- Use a project centric folder structure, and import from a folder next to the Moldflow project folder:
  1. Click Options.
  2. Navigate to Directories tab.
  3. Enable “Default to project directory”.


Name	Date modified	Type
00_Inputs	12/03/2025 15:01	File folder
01_AMI2026R01_MyProject	10/04/2026 18:36	File folder
01_AMI2027R0_MyProject	10/04/2026 18:36	File folder
02_Outputs	12/03/2025 15:01	File folder



# Meshing

## Try different parameters




- Try different parameters, small changes matter:
  - When using auto sizing, try with values like 0.7 or 1.2.
  - Give the old “Global parameters” method a try.



# Meshing

## Fusion tip: Validate and repair



- Rely on a CAD software like Fusion to repair the CAD model:
  - Change to parametric modeling mode.
  - In Validate tool, enable repair and try different parameters.
- Delete faces, stitch, unstitch, and create patches.



# Meshing

## Fusion last resort: Tessellate


1. Import the model in Fusion.
2. In the Mesh ribbon click Tessellate.
3. Adjust parameters:
  - Surface deviation, will control thickness mapping.
  - Normal deviation, will cap the triangles size.
  - Aspect ratio, will influence general quality.
4. Export from Fusion in STL format.
5. Import in Synergy and mesh.



# API Automation

## Example: Human readable results in screenshots

- On typical screenshots, the scales and values are barely readable.
- Strategy one: Make text larger
  - Pros: You may want to keep it for regular daily use.
  - Cons: If not happy with it, it requires manual adjustment on every use.
- My suggested strategy: Make image smaller and report friendly.
  - Pros: It can be automated! No need to resize once pasted.
  - Cons: None to me!



```
SetViewSize_Big_1168x750.py x
1 # %RunPerInstance
2
3 from moldflow import Synergy
4
5 synergy = Synergy()
6 viewer = synergy.viewer
7 viewer.set_view_size(1168, 750)
```

# API Automation

## Example: Automated deletion of RFN files


- Nobody likes it, but sometimes we must delete RFN files.
- It can be easily automated, starting with the project opened in Synergy:
  - Read project folder.
  - Close project.
  - Delete RFN files.
  - Reopen project.

```
1 | # %RunPerInstance
16 | import os
17 | from moldflow import Synergy
18 |
19 | # Delete files based on folder path and file name extension
20 | def delete_files_with_extension(folder_path, file_extension):
21 |     # Remove trailing backslash if it exists
22 |     print(folder_path)
23 |     if folder_path.endswith('\\'):
24 |         folder_path = folder_path[:-1]
25 |
26 |     # Loop through the files in the folder
27 |     for file_name in os.listdir(folder_path):
28 |         # Check if the file has the specified extension
29 |         if file_name.lower().endswith('.' + file_extension.lower()):
30 |             file_path = os.path.join(folder_path, file_name)
31 |             os.remove(file_path)
32 |             # print(f"Deleted file: {file_path}")
33 |
34 | # Check if the project object is actually valid/open
35 | def check_active_project(project):
36 |     if project is None:
37 |         # MessageBox.error("Project must be open before running this script.")
38 |         sys.exit()
39 |
40 | synergy = Synergy()
41 | # Read active project into "project"
42 | project = synergy.project
43 | # Call check_active_project to make sure there was an active project.
44 | check_active_project(project)
45 | # Extract path from project while the object still exists.
46 | project_path = project.path
47 | # Close the project.
48 | project.close()
49 | # Call the delete_files_with_extension function with arguments project_path and "rfn" (the target files).
50 | delete_files_with_extension(project_path, "rfn")
51 | # Reopen the most recent project, which happens to be the one we just closed.
52 | synergy.open_recent_project(0)
```

# API Automation

## Example: Add information to study notes

- Study notes are a handy place to store information.
- Can be reviewed without opening the study, by hovering over it.
- It can be easily automated, starting with the project opened in Synergy:
  - Collect existing notes as temporary notes.
  - Find plots by name.
  - Query values from plots (max, min).
  - Append information to temporary notes.
  - Once collected, write notes to study.





```
1 | %%RunPerInstance
19 | from moldflow import Synergy
20 | int_decimals = 2
21 | synergy = Synergy()
22 | study_doc = synergy.study_doc
23 | plot_manager = synergy.plot_manager
24 | viewer = synergy.viewer
25 | str_notes = study_doc.notes
26 | plot = plot_manager.find_plot_by_name("Fill time")
27 | max = plot.max_value
28 | str_notes += f"Fill time: {max:.{int_decimals}f} s\r\n"
29 | plot = plot_manager.find_plot_by_name("Pressure at V/P switchover")
30 | max = plot.max_value
31 | str_notes += f"Max. V/P pressure: {max:.{int_decimals}f} MPa\r\n"
32 | str_notes += f"\r\nWarpage data:\r\n"
33 | str_results = [
34 |     "Deflection, all effects:Deflection",
35 |     "Deflection, all effects:X Component",
36 |     "Deflection, all effects:Y Component",
37 |     "Deflection, all effects:Z Component"]
38 | for str in str_results:
39 |     plot = plot_manager.find_plot_by_name(str, "Deflection, all effects")
40 |     min = plot.min_value
41 |     max = plot.max_value
42 |     formatted_values = (
43 |         f"{str}\r\n"
44 |         f"\t\tMinimum: {min:.{int_decimals}f} mm\r\n"
45 |         f"\t\tMaximum: {max:.{int_decimals}f} mm\r\n"
46 |     )
47 |     str_notes += formatted_values
48 |     # Hide the plot
49 |     viewer.hide_plot(plot)
50 | study_doc.notes = str_notes
51 |
```

# API Automation

## Example: Confirm installed Moldflow Materials Database version

- It's hard to find:
  - When no update is installed, it's not listed in add or remove programs.
  - Only updates are listed.
- The actual information is in the Windows Registry. Until reported somewhere else, let's check it through scripting.



# API Automation

## Highlights: The new Python interface

- It's an addon, VBScripts still work!
- The documentation is available online at [Moldflow API](#). If using an AI tool, configure it to check it.
- Update cycle is decoupled from main Moldflow release. Check for updates and [Manage Synergy's Python Interface!](#)
- Scripts launched within Synergy:
  - Run within a self-contained Python virtual environment (venv) in the user's local "appdata" folder.
  - Extra packages (python-pptx, NumPy, etc.) must be added to the venv.
- Scripts launched outside Synergy:
  - Run in the default Python environment in the computer.
  - Extra packages are added to the main Python environment.

# Valuable resources



 AUTODESK

# Autodesk University classes

- Reporting:
  - [Learn to Create Professional, Stunning Reports with MS Office and the Synergy API](#)
- Simulation strategies and warpage results interpretation:
  - [Battle Royale—a Clash of Injection Molding Approaches Using Moldflow Insight](#)
  - [Battle Royale—Round 2: The Continued Clash of Approaches Using Simulation Moldflow](#)
- Synergy API fundamentals:
  - [The Autodesk Moldflow Synergy API part 1: An Introduction](#)
  - [The Autodesk Moldflow Synergy API part 2: Building real world applications](#)
- [Autodesk University site](#)

# Moldflow Summit

- Moldflow Summit 2025:
  - Tips and Tricks from the Detroit Moldflow User Group
  - Improving Part Dimensions Through Mold Compensation (Windage)
  - Moldflow Mondays – Round 2
- Moldflow Summit 2024:
  - Shrinkage adjusted constraints: Volvo's solution to warpage challenges
  - The unsung heroes: stories from the Moldflow help desk
  - Moldflow Insight: Where voids go to hide (and how to find them)
- Moldflow Summit 2023:
  - Moldflow Monday's - Miscellaneous Moldflow concepts, workflows, & best practices
  - Shrinkage compensation, and what to do with it?
- [Moldflow Summit site](#)

# Key take-overs

## What you should remember?

- Contact Autodesk Support, we are here to help you!
- Customize your environment to suite your needs.
- Give Synergy API automation a try!
- Invest time on yourself: Explore all available resources.



Autodesk and the Autodesk logo are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders. Autodesk reserves the right to alter product and services offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document. © 2026 Autodesk. All rights reserved.